


Follow the steps below to pair your WaySPORTi™ wireless earbuds to your Samsung TV for immersive surround sound:


The Bluetooth headphones must be powered on and in pairing mode before following these steps. Please consult the manual for your WaySPORTi™ for steps on placing them into pairing mode.

1. Press **MENU/123** on the remote.


2. Navigate to and select Menu.




3. Select the Sound sub menu.



4. Select Speaker Settings.




5. Navigate to and select Bluetooth Headphone List.




6. The TV scans for Bluetooth devices to connect.




7. The headphones (Scosche HFBT300) appear in the list and the message "Needs pairing" is displayed to the right. Select the headphones (Scosche HFBT300).



8. The TV pairs to the headphones (Scosche HFBT300).




9. The Bluetooth headphones are now connected to the TV. Select Ok to continue.




10. Select Close.

ENJOY IMMERSIVE SURROUND SOUND WITH YOUR WaySPORTi™ Earbuds!



Note: While the Bluetooth headphones are on you will be able to select them in the speaker select list.



Troubleshooting: If you experience any Samsung TV connection difficulties, please see your Samsung TV user manual.